



Description	Part No	Pcs
Top cap assembly		2
Preload tube	60060-05	2
Spring	68008-75	2
Washer	04752-03	2
Sleeve	61123-09	2
Sticker Öhlins white	01185-01	2
Sticker Öhlins blue	00192-01	2

Note!

Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

Warning!

Öhlins cannot be held responsible for any personal injury or damage that may occur after installing the Öhlins spring kit. We strongly recommend to let an Öhlins authorized service center to install this kit.

Warning!

After you have installed this product, take a test ride at low speed to be sure that your vehicle has maintained stability.

Note!

Please note that this image is a general representation of the product and may differ slightly from your product.

Note!

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

Fork Spring Kit for Honda CB650F & CBR650F


FSK 105

Mounting Instructions




MOUNTING INSTRUCTIONS

Original Front Fork assembly



MOUNTING INSTRUCTIONS

Öhlins Front Fork kit assembly



MOUNTING INSTRUCTIONS

Congratulations!

With this purchase you have made a clear statement. This high performance Front Fork spring kit from Öhlins is nothing but pure racing breed which means that you have taken one more step to eliminate luck on your motorcycle.

The balance between your Front Fork and rear suspension will sharpen up and the performance of your Front Fork will improve. Almost 40 years of racing experience is now a crucial part of your riding experience.

Note!

Öhlins FSK 105 gives the possibility to adjust the spring preload -5/+15mm from standard preload (13mm). > Every complete turn equal 1mm adjustment

Note!

Öhlins FSK 105 spring 68008-75 rate is 7.5N/mm

Recommended oil

We recommended to use Öhlins high performance Front Fork fluid 01316-01.

Recommended oil Level

140mm.

Note!

The measurement of oil level is taken from the top of the inner tube (5) to the oil surface.

> The fork leg need to be in vertical position

> The fork need to be fully compressed

> The fork must be without the spring and the preload tube

CB650F

How to install

1.Put the motorcycle on the work stand so that the front wheel barely touch the ground. Make sure the motorcycle is in a stable position.

2.Release the fork tube from the top triple clamp.3.Remove the original Top cap (1), Pre-load tube (2), and Spring (3)

4.Insert the Öhlins spring (8), Spring washer (5), Öhlins Pre-load tube (7)

5.Install the Öhlins Top cap assembly. Tighten the top cap at torque value ~10N/mm.

CBR650F

How to install

1.Put the motorcycle on the work stand so that the front wheel barely touch the ground. Make sure the motorcycle is in a stable position.

2.Release the fork tube from the top triple clamp.3.Remove the original Top cap (1), Pre-load tube (2), and Spring (3)

4.Insert the Öhlins spring (8), Spring washer (5), Öhlins Pre-load tube (7) and Sleeve (9)

5.Install the Öhlins Top cap assembly. Tighten the top cap at torque value ~10N/mm.

Ohlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited. To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

> Part no. MI_FSK105_EN_1 Issued 2016-11-28

Öhlins Racing AB Box 722 SE-194 27 Upplands Väsby, Sweden Phone +46 8 590 025 00 fax +46 8 590 025 80 ISO 9001 BUREAU VERITAS Certification





www.ohlins.com