

Note!

Please note that this image is a general representation of the product and may differ slightly from your product.

Note!

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

Note!

Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

Kit Contents

Description	Part No	Pcs
Shock absorber	YA110003	1
Sticker Öhlins	00192-01	2
C-spanner	00710-01	1
Owner's manual	07421-02	1

Warning!

Before installing this product, read the Öhlins Owner's Manual. The shock absorber is an important part of your vehicle and will affect the stability.

Shock Absorber for YAMAHA R15

YA110003

Mounting Instructions

MOUNTING INSTRUCTIONS

Warning!

It is advisable to have an Öhlins dealer install the shock absorber.

Warning!

If working on a raised vehicle, ensure it is securely supported so that it will not tip over.

Note!


Before mounting this product clean the vehicle thoroughly.

Note!

When working on this product, always see the Vehicle Service Manual for vehicle specific procedures and important data.


1

Put the motorcycle on a work stand so that the rear wheel barely touches the ground.



2

Remove the passenger seat by unlocking it with ignition key.





MOUNTING INSTRUCTIONS

3

Release the seat cowl by loosening the two screws.



3



4

Remove the driver seat by loosening the two bolts.

4





MOUNTING INSTRUCTIONS

5

Remove the rear cowl by loosening the two screws.




5



6

Remove the rear fairing on the right side by loosening the bolt and the screw.

6





MOUNTING INSTRUCTIONS

7

Remove the center fairing on the right side by loosening the three screws.

7






MOUNTING INSTRUCTIONS

8

Release the pull rod by loosening the bolt (1).
Loosen the lower and the upper mounting bolt
of shock absorber (2)(3).
Remove the standard shock absorber from
the motorcycle.

8






MOUNTING INSTRUCTIONS

9

9

Install the Ohlins shock absorber by tightening the upper and the lower bolts(1)(2).



10

Reverse all procedures.

Note!

Lower the vehicle so that the suspension is slightly compressed before tightening the screws.


Caution!

Ensure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber when the suspension is fully compressed or extended.

ADJUSTMENTS

⚠ Warning!

Before riding, always make sure that the basic settings made by Öhlins are according to recommended Set-up Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.



SET-UP DATA

Recommended set-up		Shock absorber data	
Spring Preload	11 mm	Length	264 mm
		Stroke	52 mm
Spring			
Part No	60281-10		
Free spring length	165 mm		

👁 Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

Part no. MI_YA110003_EN_2
Issued 2014-06-25

© Öhlins Asia Co. Ltd. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

Öhlins Asia Co. Ltd
700/937 Moo5, Tambol Nongkhaga,
Amphur Phantong, Chonburi Province
20160 Thailand



www.ohlins.com