

Note!

Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

Kit Contents

Description	Part No	Pcs
Shock absorber	YA110023	1
Sticker Öhlins	00192-01	2
C-spanner	00710-02	1
Owner's manual	07421-02	1
Bracket	60006-09	1
Bracket reservoir	03102-15	1
Screw M6x12	01046-36	2
Screw M6x14	00382-16	1

Note!

Please note that this image is a general representation of the product and may differ slightly from your product.

Note!

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

▲ Warning!

Before installing this product, read the Öhlins Owner's Manual. The shock absorber is an important part of your vehicle and will affect the stability.

Shock Absorber for Yamaha Spark/Exciter150

YA110023

Mounting Instructions



▲ Warning!

It is advisable to have an Öhlins dealer install the shock absorber.

▲ Warning!

If working on a raised vehicle, ensure it is securely supported so that it will not tip over.

1


Put the motorcycle on the center stand, so that the rear wheel barely touch the ground. Make sure the motorcycle is in a stable position.

Note!

Before mounting this product clean the vehicle thoroughly.


Note!

When working on this product, always see the Vehicle Service Manual for vehicle specific procedures and important data.




2

Open the seat.




3

Remove the rear panel by loosening the two screws then remove the storage cover.




1

Remove the grab bar by loosening the four screws.




5

Remove the fairings on both sides by loosening the 5 scews.



6

Remove the passenger footpeg by loosening the two screws and the chain guard by loosening the three screws.



Remove the standard shock by loosening the upper and the lower mounting bolts.




8

Install Öhlins Shock absorber by tightening the two mounting bolts at the torque value specified in Yamaha service manual.

Fit the plate bracket between the footpeg and the frame.

Fit the reservoir into the mounting bracket.



9

Reverse all procedures as required.

Note!

Lower the vehicle so that the suspension is slightly compressed before tightening the screws.




Ensure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber when the suspension is fully compressed or extended.

ADJUSTMENTS

▲ Warning!

Before riding, always make sure that the basic settings made by Öhlins are according to recommended Set-up Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.



SET-UP DATA

Recommended set-up

Spring

 Part No
 60015-90

 Free spring length
 85 mm

 Preload adjustment range
 [0-6]mm

Shock absorber data

 Length
 208 mm

 Stroke
 31 mm

Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

© Öhlins Asia Co. Ltd. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

Part no. MI_YA110023_1 Issued 2016-04-26

Öhlins Asia Co. Ltd 700/937 Moo5, Tambol Nongkhaga, Amphur Phantong, Chonburi Province 20160 Thailand



